




# ATXM-A CTXM-A FTXM-A






Required space for service and ventilation





Minimum space for air passage



Dimensions of fully opened front panel



Standard location of holes in the wall  
802



Notes  
1. The . mark shows the piping direction.

