





Required space for service and ventilation





Wireless remote control

ARC466A85






Left side

Standard location of holes in the wall



Blade angle



- Front grille fixing screws
Located inside of the unit
- Horizontal blade
- Right side

- Nameplate
Located inside of the unit
- Terminal block with earth terminal
Located inside of the unit
- Wi-Fi label
Located inside of the unit
- Indoor unit On/OFF switch
- Intelligent Eye Lamp
Operation Lamp
- Signal receiver
Humidity sensor
Located inside of the unit